USB-4702

10 kS/s, 12-bit, USB Multifunction Module

User Manual

Copyright

The documentation and the software included with this product are copyrighted 2009 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation.

Microsoft Windows and MS-DOS are registered trademarks of

Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

1st Edition August 2009

Printed in Taiwan

USB-4702 User Manual

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
- 2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from your dealer. This allows us to process your return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

This product has passed the CE test for environmental specifications when shielded cables are used for external wiring. We recommend the use of shielded cables. This kind of cable is available from Advantech. Please contact your local supplier for ordering information.

Technical Support and Assistance

- Step 1. Visit the Advantech web site at **www.advantech.com/support** where you can find the latest information about the product.
- Step 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Document Feedback

To assist us in making improvements to this manual, we would welcome comments and constructive criticism. Please send all such - in writing to: support@advantech.com

Safety Precaution - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- 1. To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- 2. Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

CE

Contents

Chapter	1	Introduction	. 2
-	1.1	Features	2
	1.2	Software Overview	3
		1.2.1 More on the CD	3
Chapter	2	Installation	. 6
_	2.1	Unpacking	6
	2.2	Driver Installation	7
	2.3	Hardware Installation	9
	2.4	Hardware Uninstallation	9
		Figure 2.1:Unplug or Eject Hardware Dialog	. 10
		Figure 2.2:Stop a Hardware device dialog box	. 10
Chapter	3	Signal Connections	12
_	3.1	Overview	. 12
	3.2	I/O Connectors	. 12
		3.2.1 Pin Assignments	. 12
		Figure 3.1:I/O Connector Pin Assignment	. 12
		3.2.2 I/O Connector Signal Description	13
		Table 3.1:I/O Connector Signal Description	. 13
	3.3	Analog Input Connections	. 13
		3.3.1 Single-ended Channel Connections	. 13
		Figure 3.2:Single-Ended Input Channel Connection	. 14
		3.3.2 Differential Input Connections	. 14
		Figure 3.3:Differential Input Channel Connection	. 15
	3.4	Analog Output Connections (Voltage)	. 15
		Figure 3.4: Analog Output Channel Connections	. 15
	3.5	External Trigger Source Connections	. 16
	3.6	Field Wiring Considerations	. 16
Appendix	ĸА	Specifications	18
	A.1	Analog Input	18
	A.2	Analog Output	19
	A.3	Non-Isolated Digital Input/Output	19
	A.4	Counter	19
	A.5	General	. 19

USB-4704 User Manual

CHAPTER

Introduction

This chapter will provide information on the features of the DAS module, a quick start guide for installation, and some brief information on software and accessories for USB-4702 Module.

Sections include:

- Features
- Software Overview

Chapter 1 Introduction

Thank you for buying the Advantech USB-4702 data acquisition module. The Advantech USB-4702 is a powerful data acquisition (DAS) module for the USB port. It features a unique circuit design and complete functions for data acquisition and control.

1.1 Features

USB-4702 has the most requested measurement & control functions:

- 8 single-ended/ 4 differential or combination analog input channels
- 12-bit resolution A/D converter, with up to 10 kS/s sampling rate
- 8 digital input & 8 digital output channels (TTL Level)
- 2 analog output channels
- 16-bit programmable counter/timer x 1
- Programmable gain for each analog input channel
- Automatic channel/gain scanning
- Onboard 512K samples FIFO buffer for AI channels
- Bus-powered
- Supports high-speed USB 2.0
- Auto calibration function
- Hot swappable
- Note: The USB chip on your system may have a limitation on the number of USB devices it will support. Normally, only five USB-4702 devices can be supported.
- Note: The power output of an USB port is 500 mA, while the USB-4702 requires 500 mA (max.). This means that if an USB hub is used, it will need an external power supply to support more than one USB-4702 device.

1.2 Software Overview

Advantech offers a rich set of DLL drivers, third-party driver support and application software on the companion CD-ROM to help fully exploit the functions of your device. Advantech's Device Drivers feature a complete I/O function library to help boost your application performance and work seamlessly with development tools such as Visual C++, Visual Basic, Inprise C++ Builder, and Inprise Delphi.

1.2.1 More on the CD

For instructions on how to begin programming in each development tool, Advantech offers some tutorial chapters in the Device Drivers Manual for your reference. Please refer to the corresponding sections in these chapters on the Device Drivers Manual to begin your programming efforts. You can also look at the example source code provided for each programming tool, since they can get you very well oriented.

The Device Drivers Manual can be found on the companion CD-ROM. Alternatively, if you have already installed the Device Drivers on your system, The Device Drivers Manual can be readily accessed through the Start button:

Start/Programs/Advantech Automation/Advantech Device Manager / Device Driver's Manual

After you install the examples, (in CD-ROM:\Example\) the example source code can be found under the corresponding installation folder such as the default installation path:

\Program Files\Advantech\ADSAPI\Examples

USB-4702 User Manual

CHAPTER CHAPTER

Installation

Sections include:

- Unpacking
- Driver Installation
- Hardware Installation
- Hardware Uninstallation

Chapter 2 Installation

2.1 Unpacking

After receiving your USB-4702 package, please inspect its contents first. The package should contain the following items:

- USB-4702 Module
- Shielded USB 2.0 Cable (1.8 m)
- Companion CD-ROM (DLL driver included)
- User Manual

The USB-4702 Module harbors certain electronic components vulnerable to *electrostatic discharge* (ESD). ESD could easily damage the integrated circuits and certain components if preventive measures are not carefully paid attention to. *Before removing the module from the antistatic plastic bag, you should take following precautions to ward off possible ESD damage:*

- Touch the metal part of your computer chassis with your hand to discharge static electricity accumulated on your body. One can also use a grounding strap.
- Make contact between the antistatic bag and ground before opening.

After taking out the module, you should first:

Inspect the module for any possible signs of external damage (loose or damaged components, etc.). If the module is visibly damaged, please notify our service department or our local sales representative immediately. Avoid using a damaged module with your system.

• Avoid physical contact with materials that could hold static electricity such as plastic, vinyl and Styrofoam.

2.2 Driver Installation

We recommend you install the software driver before you install the USB-4702 module into your system, since this will guarantee a smooth installation process.

The 32-bit DLL driver Setup program for the USB-4702 module is included on the companion CD-ROM that is shipped with your module package. Please follow the steps on the following page to install the driver software:



For further information on driver-related issues, an online version of the Device Drivers Manual is available by accessing the following path:

Start\Programs\Advantech Automation

\Device Manager\Device Driver's Manual

USB-4702 User Manual

2.3 Hardware Installation

Note: Make sure you have installed the software driver before you install the module (please refer to Section 2.2 Driver Installation)

After the DLL driver installation is completed, you can now go on to install the USB-4702 module in any USB port that supports the USB 1.1/2.0 standard, on your computer. Please follow the steps below to install the module on your system.

Step 1: Touch the metal part on the surface of your computer to neutralize the static electricity that might be in your body.

Step 2: Plug your USB module into the selected USB port. Use of excessive force must be avoided; otherwise the module might get damaged.

Note: In case you installed the module without installing the DLL driver, Win2000/XP will recognize your module as an "unknown device". After reboot, it will prompt you to provide necessary driver. You should ignore the prompting messages and set up the driver according to the steps described in Sec.2.2.

After your module is installed, you can configure it using the Advantech Device Manager. The Device Driver's Manual can be found at:

Start\Programs\Advantech Automation\Advantech Device Manager\Device Driver's Manual

2.4 Hardware Uninstallation

Though the Advantech USB modules are hot swappable, we still recommend you to follow the hardware un-installation procedure to avoid any unpredictable damages to your device or your system.

Step1: Close the applications of the USB module.

Step2: Right click the "Unplug or Eject Hardware" icon on your task bar.



Figure 2.1: Unplug or Eject Hardware Dialog

Step3: Select "Advantech USB-4702 Device" and press "Stop" Button.

🍫 Stop a Hardware device							
Confirm devices to be stopped, Choose OK to continue.							
Windows will attempt to stop the following devices. After the devices a stopped they may be removed safely.	re						
Advantech USB4702 Device							
OK Cano	;el						

Figure 2.2: Stop a Hardware device dialog box

Step4: Unplug your USB device from the USB port.

Note: Please make sure that you have closed the application before unplugging the USB device, otherwise unexpected system error or damage may occur.

CHAPTER 3

Signal Connections

This chapter provides useful information on how to connect input and output signals to the USB-4702 via the I/O connectors.

Sections include:

- Overview
- I/O Connectors
- Analog Input Connections
- Analog Output Connections
- Trigger Source Connections
- Field Wiring Considerations

Chapter 3 Signal Connections

3.1 Overview

Maintaining good signal connections is one of the most important factors in ensuring that your application system is sending and receiving data correctly. A good signal connection can avoid unnecessary and costly damage to your PC and other hardware devices.

3.2 I/O Connectors

USB-4702 is equipped with one DB-37 connector that facilitates signal connections to the module.

3.2.1 Pin Assignments

Warning: The two ground references AGND and DGND should be used separately for their designated purpose. Do not connect them together.

	~		
A17 A15 A13	1 2 3	20 21 22	A16 A14 A12
AI1 AGND +2.5V	4 5 6 7	23 24 25	AIO AGND AGND
AO1 AGND DI1	8 9 10	26 27 28 29	AO0 AGND DI0 DI2
DI3 DI5 DI7	11 12 13	30 31 32	DI4 DI6 DO0
DO1 DO3 DO5 DO7	14 15 16 17	33 34 35 36	DO2 DO4 DO6 TRIG
DGND	19	37) +5V

Figure 3.1: I/O Connector Pin Assignment

Table 3.1: I/O Connector Signal Description						
Signal Name	Reference	Direction	Description			
AI<07>	AGND	Input	Analog Input Channels 0 through 7.			
AO0, AO1	AGND	Output	Analog Input Channels 0 and 1.			
AGND	-	-	Analog Ground.			
DI<07>	DGND	Input	Digital Input Channels 0 through 7.			
DO<07>	DGND	Output	Digital Output Channels 0 through 7.			
DGND	-	-	Digital Ground.			
COUNT	DGND	Input	Counter Input.			
TRIG	DGND	Input	A/D External Trigger.			
+2.5V	AGND	Output	2.5V DC Voltage Output.			
+5V	AGND	Output	5V DC Voltage Output.			

3.2.2 I/O Connector Signal Description

3.3 Analog Input Connections

USB-4702 supports 8 single-ended/ 4 differential analog inputs. Each individual input channel is software-selected.

3.3.1 Single-ended Channel Connections

The single-ended input configuration has only one signal wire for each channel, and the *measured voltage* (Vm) is the voltage of the wire as referenced against the common ground.

A signal source without a local ground is also called a "floating source". It is fairly simple to connect a single-ended channel to a floating signal source. In this mode, USB-4702 provides a reference ground for external floating signal sources.

Figure 3.2 shows a single-ended channel connection between a floating signal source and an input channel on USB-4702.



Figure 3.2: Single-Ended Input Channel Connection

3.3.2 Differential Input Connections

The differential input channels operate with two signal wires for each channel, and the voltage difference between both signal wires is measured. On USB-4702, when all channels are configured to differential input, up to 4 analog channels are available.

If one side of the signal source is connected to a local ground, the signal source is ground-referenced. Therefore, the ground of the signal source and the ground of the card will not be exactly of the same voltage. The difference between the ground voltages forms a commonmode voltage $(V_{\rm cm})$.

To avoid the ground loop noise effect caused by common-mode voltages, you can connect the signal ground to the *Low* input. Figure 3.3 shows a differential channel connection between a grounded-reference signal source and an input channel on USB-4702. With this connection, the PGIA rejects a common-mode voltage V_{cm} between the signal source and USB-4702 ground, shown as V_{cm} in Figure 3.3.

Note: In differential input mode, the input channel n should be used with channel n+1. (n=0,2,4,6)



Figure 3.3: Differential Input Channel Connection

3.4 Analog Output Connections (Voltage)

USB-4702 provides two analog output channels, AO0 and AO1. Figure 3.4 shows how to make analog output connections on USB-4702.



Figure 3.4: Analog Output Channel Connections

3.5 External Trigger Source Connections

In addition to pacer triggering, USB-4702also allows external triggering for A/D conversions. Please set the "External Trigger" in software first. And the external trigger function will be enabled with a low-to-high edge which comes from TRIG. It will trigger an A/D conversion on the USB-4702 module..



3.6 Field Wiring Considerations

- When you use USB-4702 to acquire data from outside, noises in the environment might significantly affect the accuracy of your measurements if due cautions are not taken. The following measures will be helpful to reduce possible interference running signal wires between signal sources and the USB-4702.
- The signal cables must be kept away from strong electromagnetic sources such as power lines, large electric motors, circuit breakers or welding machines, since they may cause strong electromagnetic interference. Keep the analog signal cables away from any video monitor, since it can significantly affect a data acquisition system.
- If the cable travels through an area with significant electromagnetic interference, you should adopt individually shielded, twisted-pair wires as the analog input cable. This type of cable has its signal wires twisted together and shielded with a metal mesh. The metal mesh should only be connected to one point at the signal source ground.
- Avoid running the signal cables through any conduit that might have power lines in it.
- If you have to place your signal cable parallel to a power line that has a high voltage or high current running through it, try to keep a safe distance between them. Or place the signal cable in a right angle to the power line to minimize the undesirable effect.



Specifications

A.1 Analog Input

Channels	8-ch Single-ended/ 4-ch differential										
Resolution	Single-ended: 11 bits Differential: 12 bits										
FIFO Size	512 b	512 bytes									
Sampling Rate	10 kS	10 kS/s									
Input Range	Gain		1	20	16	10	8	5	4	2	1
and Gain List	Gain	Code	4	5	2	9	1	10	0	4	15
	S/E (V)	±10	-		-	-	-	-	-	-
	Differ	ential (V)	-	±1	±1.25	±2	±2.5	±4	±5	±10	±20
Drift	Gain	G =	G = 1 to 20 V/V								
	Zero (uV/'C)		9								
	Gain	(ppm/°C)	30								
Small Signal	Gain		G = 1 to 20 V/V								
Bandwidth for PGA	Bandwidth (MHz)		0.01								
Input Protection	30V max.										
Input Impedance	127 k										
Input Common Mode Voltage	100mV										
Accuracy	DC	Gain	G = 1 to 20 V/V								
-	INLE (LSF		3) ±3								
		DNLE (LS	B)	±´	1.5						
		Gain Erro (%FSR)	r	0.	15						

A.2 Analog Output

Channels	2	2				
Resolution	12 bits	12 bits				
Output range	0~5 V	0~5 V				
Throughput	150 Hz Ma	150 Hz Max, software-timed				
Output Impedance	51 ohm					
Driving Capability	5mA					
Accuracy	DC INI DN	_E ILE	±12LSB ±5LSB			
Dynamic Performance	Slew rate		0.7 V/us			
-	Setting Tir	ne	10uS			

A.3 Non-Isolated Digital Input/Output

Input Channels	8 TTL	
Input Voltage	Low	0.8 V max.
	High	2.0 V min.
Output Channels	8 (TTL)	
Output Voltage	Low	0.4V max.
	High	3.5V min.

A.4 Counter

Channels	1			
Resolution	32 bits			
Input Frequency	5 MHz max	ζ.		
Input Voltage	Low	0.8 V max.		
	High	2.0 V min.		

A.5 General

I/O Connector Type	1 x DB37 fe	male connector		
Dimensions	70 x 70 mm (2.76" x 2.76")			
Power Consumption	Typical: +5 \	/ @ 100 mA; Max.: +5 V @ 500 mA		
Temperature	Operation	0~55° C (32~131° F) (refer to IEC 68-2-1,2)		
	Storage	-20~70° C (-4~158° F)		
Relative Humidity	5~95% RH r	non-condensing (refer to IEC 68-2-1,2)		

USB-4702 User Manual