SOP of BIOS Update on Windows 10 Desktop

1. First, check the tablet that is AT or AC.



2. Copy the BIOS file to the desktop. (For here is the AT module.)



3. Execute it as Admin.



4. Click OK.

		3			
gConti	ol. FirmwareU	MVWM	I DA THE I REAL PROPERTY AND A DISARD STATES AND		
	Insyde H2OFFT v				
		Caution	×		1_x37781_WF
-Toud	F	A	Warning: You are about to update your system firmware.		Туре
			applications.		
			(1) Do not put the system into standby or hibernation (2) Do not launch other applications		
grade	S.		(3) Do not press Power button, open/close LID, dock/undock system, insert or remove USB, 1394 or any other device		
			The system will be forced to restart when BIOS flashing process finished.		
2 ob	Current		Do not do BIOS update during Windows Update. Do not hot plug USB device and AC Power during BIOS flashing	-	
seo	Version v		***************************************		
	New		Click OK to start or Cancel to return to main window.	~	
	Version 🛛				
etc					
ļ			OK Cancel		
ditor	our op	con			
		Cent 1 it	em 1 item selected 4.65 MB	and the second second	

5. It will run amount 3 minutes, please wait.

			_x37781_WI
FA	(cinsudo"		Туре
-Cart	Emisyde		Applica
	Insyde H2OFFT (Flash Firmware Tool) Version 5.61		
Current	Eracing and Milling		
Vienter 12 700			
New			
		~	
Version ×3.7781	98%		
Doi	not turn off your computer		
S of the second			
Cent 1 item 1 it	em selected 4.65 MB		

6. When finished, it will auto reboot.



7. We can type **dxdiag** to check our BIOS version is **x3.778**.

Best m	atch							Pullieu ii	normación i	noout the t	ARECTA CON	ponents a	nd drivers instal	led on you	ur system.	
8	dxdiag Run cor) nmand				1	ow what a visit each	area is ci page in	ausing the sequence.	problem, cl	ick the app	propriate tz	ab above. Othe	nvise, you	can use the "Next	Page" b
					-	_			Current	Date/Time	r. Monday	August 1	0 2010 4-10-1			
									Com	outer Name	DESKTO	P-DE4IOG	9, 2019, 4.10:1. II	> 1991		
									Operat	ting System	: Window	s 10 Enter	prise 2016 LTSB	64-bit (10	0.0. Ruild 14393)	
						Language: English (Regional Setting: English)										
									System Ma	anufacture	: Insyde	Activity Count				
									Sy	stem Mode	: CherryTi	rail				
										BIOS	: x3.778I					
										Processor	: Intel(R)	Atom(TM)	x5-28350 CPU	@ 1.44GH	Hz (4 CPUs), ~1.4G	tz
										Memory	: 2048MB	RAM				
										Page file	: 2319MB	used, 355	MB available			
									Dire	ctx version	: DirectX :	12				
							ck for WHQ	QL digita	I signature	5						
											DxDiag 10	.00.14393	.0000 64-bit Un	icode Cop	yright © Microsoft	. All right
							Help						Next Page		Save All Informat	ion
F	(\$)	D			□3	10	putty	Sin	npleText	DevCo	n Fi	irefox				
	1000															

 Or you can even check in BIOS, press ESC when power on, and then go into [Setup Utility].

4	Insyde' Marine M	16:19:19	16	
	\bigcirc			
	Continue The electron will dract the volten to continue to booting process	The unclaimed time pic to the and Henry of	This sector will tak you to the Bourd Marger	
	Boot From File	Administer Secure Bort	Setup Utility	
	Boot system from a file or divice		Go to Setup Utility.	



9. We can see our BIOS version is x3.7781. It's done!